COLUMNS DETAILS
Gran Via

Fira Barcelona




Hall 1	C101 to C105	page 3
Hall 2	C201 to C211	page 9
Hall 3	C301 to C305	page 21
Hall 4	C401 to C405	page 26
Hall 5	C501 to C505	page 30
Hall 6	C601 to C605	page 36
Hall 7	C701 to C705	page 41
Underwalkway	CU01 to CU04	page 47
Hall 8.0	C8001 to C8005	page 52
Hall 8.1	C8101 to C8105	page 58

INSTRUCTIONS

Please check the floorplans to locate each column type name.

Columns are named as




Technical constraints

No construction elements can be supported by or onto walls, columns or other fixed elements of the halls, and adequate protection must be used or a safe distance must be maintained between the construction materials and the hall walls. In no case should the stability of any object, assembly or structure be conditioned to the infrastructure of Fira de Barcelona. All elements must be self-supporting and self-standing.


Hall columns inside the stand can be cladded without damaging them and in accordance with the permitted height regulations, taking into account the fact that, in the case of connection boxes, these boxes can always be registered. Vinyl columns can only be installed by official Fira suppliers. This service can be contracted through the sales department of Fira Barcelona (www.servifira.com)

In the case of cladding or decorating columns with fire equipment, extinguishers, fire alarm call points, signage or any other informational element of the venue, they must always be visible and accessible. They cannot be manipulated nor broken down.

Cladding policy



A vinyl can reach up to the upper fire signage




The cladding cannot cover the upper signage

Some of the fire equipment in Halls 3, 4 and 6 include fixed switchboards. These columns are marked with the letter *b* after the type name. The swicthboards can be cladded but need to remain accessible during build up and dismantling to other exhibitors.

HALL 1
Floorplan

Fira Barcelona



Air Quality Screen	Installation Column Height (cm)
A	430

Note that air quality information screens are installed in all halls. The floor plans for each hall indicate the location and installation height of each screen.

The approximate dimensions of the screens are **75 × 45 cm**.


For further information, please contact your event organiser.

The current document only provides guidance on venue technical information for organisers.

When designing specific areas or booth spaces please always refer to the technical hall DWG available for download at this website.

Column type C101

Floorplan & Dimensions



These columns are free of fire equipment and signage. Cladding can be made following the maximum height established by the regulations of each event.

Picture




The current document only provides guidance on venue technical information for organisers.


When designing specific areas or booth spaces please always refer to the technical hall DWG available for download at this website.

Column type C102

Floorplan & Dimensions



Picture




The current document only provides guidance on venue technical information for organisers.

When designing specific areas or booth spaces please always refer to the technical hall DWG available for download at this website.

Column type C103

Floorplan & Dimensions



Picture




The current document only provides guidance on venue technical information for organisers.


When designing specific areas or booth spaces please always refer to the technical hall DWG available for download at this website.

Fira Barcelona

Column type C104

Floorplan & Dimensions





Note that the fire extinguisher equipment and sign need to remain accessible and visible at all times.

Picture




The current document only provides guidance on venue technical information for organisers.


When designing specific areas or booth spaces please always refer to the technical hall DWG available for download at this website.

Fira Barcelona

Column type C105

Floorplan & Dimensions





Note that the fire extinguisher equipment and sign need to remain accessible and visible at all times.


Picture



The current document only provides guidance on venue technical information for organisers.

When designing specific areas or booth spaces please always refer to the technical hall DWG available for download at this website.

HALL 2
Floorplan



Air Quality Screen	Installation Column Height (cm)
A	455

Note that air quality information screens are installed in all halls. The floor plans for each hall indicate the location and installation height of each screen.

The approximate dimensions of the screens are **75 × 45 cm**.

For further information, please contact your event organiser.


The current document only provides guidance on venue technical information for organisers.

When designing specific areas or booth spaces please always refer to the technical hall DWG available for download at this website.

Fira Barcelona


Column type C201

Floorplan & Dimensions



These columns are free of fire equipment and signage. Cladding can be made following the maximum height established by the regulations of each event.

Picture




The current document only provides guidance on venue technical information for organisers.

When designing specific areas or booth spaces please always refer to the technical hall DWG available for download at this website.

Column type C202


Floorplan & Dimensions


Single



These columns are free of fire equipment and signage.
Cladding can be made following the maximum height established by the regulations of each event.

Double





Picture




The current document only provides guidance on venue technical information for organisers.

When designing specific areas or booth spaces please always refer to the technical hall DWG available for download at this website.


Column type C203

Floorplan & Dimensions



These columns are free of fire equipment and signage. Cladding can be made following the maximum height established by the regulations of each event.

Picture




The current document only provides guidance on venue technical information for organisers.

When designing specific areas or booth spaces please always refer to the technical hall DWG available for download at this website.

Fira Barcelona

Column type C204

Floorplan & Dimensions



These columns are free of fire equipment and signage. Cladding can be made following the maximum height established by the regulations of each event.

Picture




The current document only provides guidance on venue technical information for organisers.

When designing specific areas or booth spaces please always refer to the technical hall DWG available for download at this website.

Column type C205


Floorplan & Dimensions



Dimensions of the base

These columns are free of fire equipment and signage. Cladding can be made following the maximum height established by the regulations of each event.

Picture




The current document only provides guidance on venue technical information for organisers.

When designing specific areas or booth spaces please always refer to the technical hall DWG available for download at this website.

Fira Barcelona

Column type C206

Floorplan & Dimensions



These columns are free of fire equipment and signage. Cladding can be made following the maximum height established by the regulations of each event.


Picture



Fira Barcelona

Column type C207

Floorplan & Dimensions



These columns are free of fire equipment and signage. Cladding can be made following the maximum height established by the regulations of each event.

Picture




The current document only provides guidance on venue technical information for organisers.

When designing specific areas or booth spaces please always refer to the technical hall DWG available for download at this website.


Column type C208

Floorplan & Dimensions



These columns are free of fire equipment and signage. Cladding can be made following the maximum height established by the regulations of each event.

Picture




The current document only provides guidance on venue technical information for organisers.

When designing specific areas or booth spaces please always refer to the technical hall DWG available for download at this website.

Fira Barcelona

Column type C209

Floorplan & Dimensions



These columns are free of fire equipment and signage. Cladding can be made following the maximum height established by the regulations of each event.


Picture



Fira Barcelona


Column type C210

Floorplan & Dimensions



These columns are free of fire equipment and signage. Cladding can be made following the maximum height established by the regulations of each event.

Picture




The current document only provides guidance on venue technical information for organisers.

When designing specific areas or booth spaces please always refer to the technical hall DWG available for download at this website.

Fira Barcelona


Column type C211

Floorplan & Dimensions



These columns are free of fire equipment and signage. Cladding can be made following the maximum height established by the regulations of each event.


Picture



The current document only provides guidance on venue technical information for organisers.

When designing specific areas or booth spaces please always refer to the technical hall DWG available for download at this website.

HALL 3
Floorplan



Air Quality Screen	Installation Column Height (cm)
A	520
B	450
C	450

Note that air quality information screens are installed in all halls. The floor plans for each hall indicate the location and installation height of each screen.

The approximate dimensions of the screens are **75 × 45 cm**.

For further information, please contact your event organiser.


The current document only provides guidance on venue technical information for organisers.

When designing specific areas or booth spaces please always refer to the technical hall DWG available for download at this website.

Fira Barcelona

Column type C301

Floorplan & Dimensions



These columns are free of fire equipment and signage. Cladding can be made following the maximum height established by the regulations of each event.

Picture





The current document only provides guidance on venue technical information for organisers.

When designing specific areas or booth spaces please always refer to the technical hall DWG available for download at this website.

Column type C302

Floorplan & Dimensions





Note that the fire extinguisher equipment and sign need to remain accessible and visible at all times.

Picture




The current document only provides guidance on venue technical information for organisers.

When designing specific areas or booth spaces please always refer to the technical hall DWG available for download at this website.


Fira Barcelona

Column type C303

Floorplan & Dimensions



main central aisle



Note that the fire extinguisher equipment and sign need to remain accessible and visible at all times. These columns include a switchboard with 12 schuko type sockets of 10A to be used during build-up only.

Picture



The current document only provides guidance on venue technical information for organisers.


When designing specific areas or booth spaces please always refer to the technical hall DWG available for download at this website.

Column details - Gran Via
Hall 3

Fira Barcelona

Column type C304

Floorplan & Dimensions



These columns are free of fire equipment and signage. Cladding can be made following the maximum height established by the regulations of each event.


Picture



The current document only provides guidance on venue technical information for organisers.

When designing specific areas or booth spaces please always refer to the technical hall DWG available for download at this website.

HALL 4
Floorplan



Air Quality Screen	Installation Column Height (cm)
A	460
B	460

Note that air quality information screens are installed in all halls. The floor plans for each hall indicate the location and installation height of each screen.

The approximate dimensions of the screens are **75 × 45 cm**.

For further information, please contact your event organiser.


The current document only provides guidance on venue technical information for organisers.

When designing specific areas or booth spaces please always refer to the technical hall DWG available for download at this website.

Fira Barcelona

Column type C401

Floorplan & Dimensions



These columns are free of fire equipment and signage. Cladding can be made following the maximum height established by the regulations of each event.


Picture




Fira Barcelona

Column type C402

Floorplan & Dimensions





Note that the fire extinguisher equipment and sign need to remain accessible and visible at all times.

Picture




The current document only provides guidance on venue technical information for organisers.


When designing specific areas or booth spaces please always refer to the technical hall DWG available for download at this website.

Column type C403

Floorplan & Dimensions



main central aisle



Note that the fire extinguisher equipment and sign need to remain accessible and visible at all times. These columns include a switchboard with 12 schuko type sockets of 10A to be used during build-up only.


Picture



The current document only provides guidance on venue technical information for organisers.

When designing specific areas or booth spaces please always refer to the technical hall DWG available for download at this website.

HALL 5
Floorplan



Air Quality Screen	Installation Column Height (cm)
A	450

Note that air quality information screens are installed in all halls. The floor plans for each hall indicate the location and installation height of each screen.

The approximate dimensions of the screens are **75 × 45 cm**.


For further information, please contact your event organiser.

The current document only provides guidance on venue technical information for organisers.


When designing specific areas or booth spaces please always refer to the technical hall DWG available for download at this website.

Column type C501

Floorplan & Dimensions



main central aisle



Note that the fire extinguisher equipment and sign need to remain accessible and visible at all times.

Picture




The current document only provides guidance on venue technical information for organisers.


When designing specific areas or booth spaces please always refer to the technical hall DWG available for download at this website.

Fira Barcelona

Column type C502

Floorplan & Dimensions





Note that the fire extinguisher equipment and sign need to remain accessible and visible at all times.

Picture




The current document only provides guidance on venue technical information for organisers.

When designing specific areas or booth spaces please always refer to the technical hall DWG available for download at this website.

Column type C503

Floorplan & Dimensions



Picture




The current document only provides guidance on venue technical information for organisers.

When designing specific areas or booth spaces please always refer to the technical hall DWG available for download at this website.

Fira Barcelona

Column type C504

Floorplan & Dimensions



Picture




The current document only provides guidance on venue technical information for organisers.

When designing specific areas or booth spaces please always refer to the technical hall DWG available for download at this website.

Fira Barcelona

Column type C505

Floorplan & Dimensions



These columns are free of fire equipment and signage. Cladding can be made following the maximum height established by the regulations of each event.


Picture



The current document only provides guidance on venue technical information for organisers.

When designing specific areas or booth spaces please always refer to the technical hall DWG available for download at this website.

HALL 6
Floorplan



Air Quality Screen	Installation Column Height (cm)
A	445
B	445

Note that air quality information screens are installed in all halls. The floor plans for each hall indicate the location and installation height of each screen.

The approximate dimensions of the screens are **75 × 45 cm**.

For further information, please contact your event organiser.


The current document only provides guidance on venue technical information for organisers.

When designing specific areas or booth spaces please always refer to the technical hall DWG available for download at this website.

Fira Barcelona

Column type C601

Floorplan & Dimensions



These columns are free of fire equipment and signage. Cladding can be made following the maximum height established by the regulations of each event.

Picture




The current document only provides guidance on venue technical information for organisers.


When designing specific areas or booth spaces please always refer to the technical hall DWG available for download at this website.

Fira Barcelona

Column type C602

Floorplan & Dimensions





Note that the fire extinguisher equipment and sign need to remain accessible and visible at all times. These columns include a switchboard with 12 schuko type sockets of 10A to be used during build-up only.

Picture




The current document only provides guidance on venue technical information for organisers.


When designing specific areas or booth spaces please always refer to the technical hall DWG available for download at this website.

Fira Barcelona

Column type C603

Floorplan & Dimensions





Note that the fire extinguisher equipment and sign need to remain accessible and visible at all times.

Picture



The current document only provides guidance on venue technical information for organisers.


When designing specific areas or booth spaces please always refer to the technical hall DWG available for download at this website.

Fira Barcelona

Column type C604

Floorplan & Dimensions

These columns are free of fire equipment and signage.
Cladding can be made following the maximum height
established by the regulations of each event.




Picture



The current document only provides guidance on venue technical information for organisers.

When designing specific areas or booth spaces please always refer to the technical hall DWG available for download at this website.

HALL 7
Floorplan



Air Quality Screen	Installation Column Height (cm)
A	450

Note that air quality information screens are installed in all halls. The floor plans for each hall indicate the location and installation height of each screen.

The approximate dimensions of the screens are **75 × 45 cm**.

For further information, please contact your event organiser.


The current document only provides guidance on venue technical information for organisers.

When designing specific areas or booth spaces please always refer to the technical hall DWG available for download at this website.


Fira Barcelona

Column type C701

Floorplan & Dimensions



main central aisle



Note that the fire extinguisher equipment and sign need to remain accessible and visible at all times.

Picture





The current document only provides guidance on venue technical information for organisers.

When designing specific areas or booth spaces please always refer to the technical hall DWG available for download at this website.

Column type C702

Floorplan & Dimensions





Note that the fire extinguisher equipment and sign need to remain accessible and visible at all times.

Picture




The current document only provides guidance on venue technical information for organisers.

When designing specific areas or booth spaces please always refer to the technical hall DWG available for download at this website.


Fira Barcelona

Column type C703

Floorplan & Dimensions



Picture




The current document only provides guidance on venue technical information for organisers.


When designing specific areas or booth spaces please always refer to the technical hall DWG available for download at this website.

Column type C704

Floorplan & Dimensions



Picture




The current document only provides guidance on venue technical information for organisers.

When designing specific areas or booth spaces please always refer to the technical hall DWG available for download at this website.

Column type C705

Floorplan & Dimensions



These columns are free of fire equipment and signage. Cladding can be made following the maximum height established by the regulations of each event.


Picture



The current document only provides guidance on venue technical information for organisers.

When designing specific areas or booth spaces please always refer to the technical hall DWG available for download at this website.

UNDERWALKWAY
Floorplan




The current document only provides guidance on venue technical information for organisers.

When designing specific areas or booth spaces please always refer to the technical hall DWG available for download at this website.

Fira Barcelona

Column type CU01

Floorplan & Dimensions



These columns are free of fire equipment and signage. Cladding can be made following the maximum height established by the regulations of each event.

Picture




The current document only provides guidance on venue technical information for organisers.

When designing specific areas or booth spaces please always refer to the technical hall DWG available for download at this website.


Fira Barcelona

Column type CU02

Floorplan & Dimensions



Picture




The current document only provides guidance on venue technical information for organisers.

When designing specific areas or booth spaces please always refer to the technical hall DWG available for download at this website.

Fira Barcelona

Column type CU03

Floorplan & Dimensions



Picture




The current document only provides guidance on venue technical information for organisers.

When designing specific areas or booth spaces please always refer to the technical hall DWG available for download at this website.

Fira Barcelona

Column type CU04

Floorplan & Dimensions




Picture



The current document only provides guidance on venue technical information for organisers.

When designing specific areas or booth spaces please always refer to the technical hall DWG available for download at this website.

HALL 8.0
Floorplan



Air Quality Screen	Installation Column Height (cm)
A	350

Note that air quality information screens are installed in all halls. The floor plans for each hall indicate the location and installation height of each screen.

The approximate dimensions of the screens are **75 × 45 cm**.

For further information, please contact your event organiser.


The current document only provides guidance on venue technical information for organisers.


When designing specific areas or booth spaces please always refer to the technical hall DWG available for download at this website.

Fira Barcelona

Column type C8001

Floorplan & Dimensions





Note that the fire extinguisher equipment and sign need to remain accessible and visible at all times.

Picture




The current document only provides guidance on venue technical information for organisers.

When designing specific areas or booth spaces please always refer to the technical hall DWG available for download at this website.


Fira Barcelona

Column type C8002

Floorplan & Dimensions



main central aisle



Note that the fire extinguisher equipment and sign need to remain accessible and visible at all times.

Picture




The current document only provides guidance on venue technical information for organisers.

When designing specific areas or booth spaces please always refer to the technical hall DWG available for download at this website.

Fira Barcelona

Column type C8003

Floorplan & Dimensions



Picture




The current document only provides guidance on venue technical information for organisers.


When designing specific areas or booth spaces please always refer to the technical hall DWG available for download at this website.

Column type C8004

Floorplan & Dimensions



Picture




The current document only provides guidance on venue technical information for organisers.

When designing specific areas or booth spaces please always refer to the technical hall DWG available for download at this website.

Fira Barcelona

Column type C8005

Floorplan & Dimensions




These columns are free of fire equipment and signage. Cladding can be made following the maximum height established by the regulations of each event.

Picture



HALL 8.1
Floorplan




The current document only provides guidance on venue technical information for organisers.


When designing specific areas or booth spaces please always refer to the technical hall DWG available for download at this website.

Fira Barcelona

Column type C8101

Floorplan & Dimensions





Note that the fire extinguisher equipment and sign need to remain accessible and visible at all times.

Picture




The current document only provides guidance on venue technical information for organisers.

When designing specific areas or booth spaces please always refer to the technical hall DWG available for download at this website.


Fira Barcelona

Column type C8102

Floorplan & Dimensions



Picture




The current document only provides guidance on venue technical information for organisers.

When designing specific areas or booth spaces please always refer to the technical hall DWG available for download at this website.

Fira Barcelona

Column type C8103

Floorplan & Dimensions



Picture



The current document only provides guidance on venue technical information for organisers.

When designing specific areas or booth spaces please always refer to the technical hall DWG available for download at this website.